


INSTALLATION INSTRUCTIONS

HIGH-EFFICIENCY CONDENSING UNITS

FEATURING EARTH-FRIENDLY R-410A REFRIGERANT



(-)AWL - 6½ & 7½ TON



RECOGNIZE THIS SYMBOL AS AN INDICATION OF IMPORTANT SAFETY INFORMATION!

▲ WARNING

THESE INSTRUCTIONS ARE INTENDED AS AN AID TO QUALIFIED, LICENSED SERVICE PERSONNEL FOR PROPER INSTALLATION, ADJUSTMENT AND OPERATION OF THIS UNIT. READ THESE INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING INSTALLATION OR OPERATION. FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN IMPROPER INSTALLATION, ADJUSTMENT, SERVICE OR MAINTENANCE POSSIBLY RESULTING IN FIRE, ELECTRICAL SHOCK, PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.



ISO 9001:2008

Certificate Number: 30164

DO NOT DESTROY THIS MANUAL

PLEASE READ CAREFULLY AND KEEP IN A SAFE PLACE FOR FUTURE REFERENCE BY A SERVICEMAN

[] INDICATES METRIC CONVERSIONS



92-42665-27-03
SUPERSEDES 92-42665-27-02

CONTENTS

1.0 Important Safety Information	3
2.0 General Information	4
2.1 Introduction	4
2.2 Importance of a Quality Installation	4
2.3 System Sizing and Selection	4
2.4 Importance of Proper Indoor/Outdoor Match-Ups	5
2.5 Checking Product Received	5
2.6 Efficiency Testing Notice	5
2.7 Compressor Break-In Notice	5
3.0 Unit Specifications	6
3.1 Model Number Nomenclature	6
3.2 Physical and Electrical Data	7
4.0 Installation	9
4.1 Tools & Refrigerant	9
4.1.1 Tools Required for Installing & Servicing R-410A Models ..	9
4.1.2 Specifications of R-410A	9
4.1.3 Quick Reference Guide for R-410A	9
4.2 Choosing a Location	10
4.2.1 Allowable Clearances	10
4.2.2 Operational Issues Related to Unit Location	10
4.2.3 Corrosive Environments	11
4.2.4 Customer Satisfaction Issues	11
4.3 Mounting Unit	11
4.3.1 Unit-Mounting Methods	11
4.3.2 High Wind and Seismic Tie-Down Methods	11
4.3.3 Elevating Unit	12
4.4 Refrigerant Line Set Selection	13
4.4.1 Replacing Existing Systems	13
4.4.2 Line Set Length and Fitting Losses	13
4.4.3 Liquid Line Selection	13
4.4.4 Suction Line Selection	15
4.4.5 Long Line Length Considerations	15
4.4.5.1 Oil Return to Compressor	15
4.4.5.2 Refrigerant Migration During Off-Cycle	15
4.4.5.3 Maximum Liquid Pressure Drop	15
4.4.5.4 Liquid Line Refrigerant Flashing	15
4.4.5.5 Compressor Oil Level Adjustment	16
4.4.5.6 Capacity Losses	16
4.5 Line Set Installation	17
4.5.1 Important Tubing Installation Practices	17
4.5.2 Relative Location of Indoor and Outdoor Units	18
4.5.2.1 Indoor and Outdoor Unit Near Same Level	18
4.5.2.2 Outdoor Unit Below Indoor Unit	19
4.5.2.3 Outdoor Unit Above Indoor Unit	20
4.5.3 Tubing Connections	21
4.6 Initial Leak Testing	22
4.7 Evacuation	22
4.8 Control Wiring	23
4.9 Typical Field Wiring Connections	23
4.10 Configuring Control Transformer for 208V Applications	24
4.11 Power Wiring	24
4.12 Grounding	24

5.0 Refrigerant Charging and System Start-Up	25
5.1 Start-Up Overview	25
5.2 Preliminary Charging by Weight and Final Leak Check	25
5.3 Pre-Start Check	26
5.4 Initial System Power-Up – Verifying Correct Indoor Blower Motor and Compressor Rotation	27
5.5 Verifying Indoor Air-Flow	27
5.6 Final Charging by Pressures	28
5.7 Charging Charts	29
5.8 Completing Installation	31
6.0 Sequence of Operation	31
7.0 Components & Controls	32
7.1 Compressor	32
7.2 Outdoor Fan Motor	32
7.3 Outdoor Fan	32
7.4 Compressor Contactor	32
7.5 Compressor Crankcase Heater	32
7.6 High and Low Pressure Controls	32
7.7 Transformer	32
8.0 Accessories	33
8.1 Compressor Time Delay	33
8.2 Compressor Sound Enclosure	33
8.3 Low Ambient Control	33
8.4 Liquid Line Solenoid	33
8.5 Sight Glass	33
9.0 Diagnostics and Troubleshooting	34
9.1 Cooling Mechanical Checks Flowchart	34
9.2 General Troubleshooting Guide	35
9.3 Service Analyzer Charts	36
9.4 Troubleshooting Tips	41
10.0 Outdoor Unit Maintenance	42
10.1 Outdoor Coil Cleaning	42
10.2 Cabinet Cleaning and Care	42
10.3 Motor Lubrication	42
10.4 Replacement Parts	42
11.0 Wiring Diagram	43

1.0 IMPORTANT SAFETY INFORMATION

⚠️ WARNINGS:

- These instructions are intended as an aid to qualified, licensed service personnel for proper installation, adjustment, and operation of this unit. Read these instructions thoroughly before attempting installation or operation. **Failure to follow these instructions may result in improper installation, adjustment, service, or maintenance possibly resulting in fire, electrical shock, property damage, personal injury, or death.**
- **The unit must be permanently grounded. Failure to do so can cause electrical shock resulting in severe personal injury or death.**
- **Turn off electric power at the fuse box or service panel before making any electrical connections.**
- **Complete the ground connection before making line voltage connections. Failure to do so can result in electrical shock, severe personal injury, or death.**
- **Disconnect all power to unit before starting maintenance. Failure to do so can cause electrical shock resulting in severe personal injury or death.**
- **Never assume the unit is properly wired and/or grounded. Always test the unit cabinet with a noncontact voltage detector available at most electrical supply houses or home centers before removing access panels or coming into contact with the unit cabinet.**
- **Do not use oxygen to purge lines or pressurize system for leak test. Oxygen reacts violently with oil, which can cause an explosion resulting in severe personal injury or death.**
- The top of the scroll compressor shell is hot. Touching the compressor top may result in serious personal injury.
- The manufacturer's warranty does not cover any damage or defect to the unit caused by the attachment or use of any components, accessories, or devices (other than those authorized by the manufacturer) into, onto, or in conjunction with the heat pump. **You should be aware that the use of unauthorized components, accessories, or devices may adversely affect the operation of the heat pump and may also endanger life and property.** The manufacturer disclaims any responsibility for such loss or injury resulting from the use of such unauthorized components, accessories, or devices.

⚠️ CAUTIONS:

- R-410A systems operate at approximately 60% higher pressures (1.6 times) than R-22 systems. Do not use R-22 service equipment or components on R-410A equipment. Use appropriate care when using this refrigerant. Failure to exercise care may result in equipment damage or personal injury.
- Only match this outdoor unit with a matched indoor coil or air handler approved for use with this outdoor unit per the unit manufacturer's specification sheet. The use of unmatched coils or air handler will likely result in a charge imbalance between the cooling and heating modes which can cause unsatisfactory operation including a high-pressure switch lockout condition.
- Only use indoor coils approved for use on R-410A systems. An R-22 coil will have a TXV or fixed restrictor device that is not designed to operate properly in an R-410A system and will result in serious operational issues. The R-22 coil could also contain mineral oil which is incompatible with the POE oil used in R-410A systems and could result in reliability issues with the compressor and TXVs.
- When coil is installed over a finished ceiling and/or living area, it is required that a secondary sheet metal condensate pan be constructed and installed under the entire unit. Failure to do so can result in property damage.
- The compressor has an internal overload protector. Under some conditions, it can take up to 2 hours for this overload to reset. Make sure overload has had time to reset before condemning the compressor.

2.0 GENERAL INFORMATION

⚠WARNING:

Improper installation, or installation not made in accordance with these instructions, can result in unsatisfactory operation and/or dangerous conditions and can cause the related warranty not to apply.

2.1 Introduction

The information contained in this manual has been prepared to assist in the proper installation, operation, and maintenance of the air conditioning system.

Read this manual and any instructions packaged with separate equipment required to make up the system prior to installation. Homeowner should retain this manual for future reference.

2.2 Importance of Quality Installation

A quality installation is critical to assure safety, reliability, comfort, and customer satisfaction. Strict adherence to applicable codes, the information in this installation manual, the outdoor unit installation manual, and the thermostat installation manual are key to a quality installation. Read the entire instruction manuals before starting the installation.

IMPORTANT: This product has been designed and manufactured to meet certified AHRI capacity and efficiency ratings with the appropriate outdoor units. However, proper refrigerant charge, proper airflow, and refrigerant line sizing are critical to achieve optimum capacity and efficiency and to assure reliable operation. Installation of this product should follow the manufacturer's refrigerant charging and airflow instructions located in this installation manual and the charging chart label affixed to the outdoor unit. Failure to confirm proper charge and airflow may reduce energy efficiency and shorten equipment life.

The equipment has been evaluated in accordance with the Code of Federal Regulations, Chapter XX, Part 3280.

Install the unit in accordance with applicable national, state, and local codes. Latest editions are available from: "National Fire Protection Association, Inc., Batterymarch Park, Quincy, MA 02269." These publications are:

- ANSI/NFPA No. 70-(Latest Edition) National Electrical Code.

- NFPA90A Installation of Air Conditioning and Ventilating Systems.

- NFPA90B Installation of warm air heating and air conditioning systems.

Install the indoor unit in such a way as to allow necessary access to the coil/filter rack and blower/control compartment.

2.3 System Sizing and Selection

Before specifying any air-conditioning equipment, a survey of the structure and heat gain calculation must be made. A heat gain calculation involves identifying all surfaces and openings that gain heat from the surrounding air and quantifying that heat to determine the amount of heat that needs to be removed. A heat gain calculation also calculates the extra heat load caused by sunlight and for humidity removal. These factors must be considered before selecting an air-conditioning system to provide year-round comfort. The Air Conditioning Contractors of America (ACCA) Manual N method of load calculation is one recognized procedure for determining the cooling load for commercial buildings.

After the proper equipment combination has been selected, satisfying both sensible and latent requirements, the system must be properly installed. Only then can the system provide the comfort it was designed to provide.

There are several factors that installers must consider.

- Outdoor unit location
- Indoor unit blower speed and airflow
- Proper equipment evacuation
- Supply and return air duct design and sizing
- Refrigerant charge
- System air balancing
- Diffuser and return air grille location and sizing

IMPORTANT: Excessive use of elbows in the refrigerant line set can produce excessive pressure drop. Follow industry best practices for installation. Installation and commissioning of this equipment is to be performed by trained and qualified HVAC professionals. For technical assistance, contact your Distributor Service Coordinator.

2.0 GENERAL INFORMATION

2.4 Importance of Proper Indoor/Outdoor Match-Ups

To assure many years of reliable operation and optimum customer comfort and to assure the outdoor unit warranty remains valid, an air-handler model or indoor coil should be selected that is properly matched to the outdoor unit. The recommended approach is to select an air-handler or indoor coil that has an AHRI match with the outdoor unit. Refer to the AHRI directory at www.ahridirectory.org to confirm the air-handler and outdoor unit are a certified combination in the AHRI Directory.

2.5 Checking Product Received

Upon receiving unit, inspect it for any shipping damage. Claims for damage, either apparent or concealed, should be filed immediately with the shipping company. Check model number, electrical characteristics, and accessories to determine if they are correct. Check system components (indoor coil, outdoor unit, air handler/furnace, etc.) to make sure they are properly matched.

2.6 Efficiency Testing Notice


For purposes of verifying or testing efficiency ratings, the test procedure in Title 10, Chapter II, Subchapter D, Part 431, Subpart F, Section 96 and the clarifying provisions provided in the AHRI Operations Manual 340/360 that were applicable at the date of manufacture should be used for test set up and performance.

2.7 Compressor Break-In Notice

Prior to agency testing, the unit must be run for 20 hours at 115°F [46.1°C] outdoor ambient temperature with 80°F [26.7°C] dry bulb/75°F [23.9°C] wet bulb indoor ambient temperature to break the compressor in.

3.0 UNIT SPECIFICATIONS

3.1 Model Number Nomenclature



3.0 UNIT SPECIFICATIONS



3.2 Electrical and Physical Data

PHYSICAL AND ELECTRICAL DATA

Model No.: (-)AWL -	079	091
Operating Weight (lbs) [kg]	245 [111.1]	307 [139.2]
Shipping Weight (lbs) [kg]	252 [114.3]	313 [141.9]
Compressor:		
Quantity	1	1
Type	Scroll	
RPM	3500	
Condenser Fans:		
Quantity	1	1
CFM [L/s]	5700 [2690]	5700 [2690]
Diameter (in.) [mm]	26 [660]	26 [660]
Motor Horsepower (ea.) [W]	1/2 [373]	1/2 [373]
Type	ECM	ECM
RPM	975	975
CONDENSER COIL:		
Quantity	1	1
Rows	1	2
Fins per Inch	22	22
Square Feet [m²]	28.38 [2.64]	32.44 [3.01]
Fins/Tubes	Aluminum / Copper	
	3/8 [10]	3/8 [10]
SERVICE VALVE NOMINAL SIZE		
Suction Line Service Valve ID	1-1/8" [28.6]	1-1/8" [28.6]
Liquid Line Service Valve ID	1/2" [12.7]	1/2" [12.7]

ELECTRICAL DATA TABLE

Model No.: (-)AWL -	079CAZ	079DAZ	079VAZ	091CAZ	091DAZ	091VAZ
COMPRESSOR MOTOR:						
Electrical Characteristics	208/230-3-60	460-3-60	380-3-60	208/230-3-60	460-3-60	380-3-60
OPERATING CURRENT:						
Rated Load Amps	25	11.8	11	27.9	13.6	13.9
Locked Rotor Amps	149	83	88	164	100	94.3
CONDENSER FAN MOTORS:						
Volts & Phase	208/230-1	460-1	380-1	208/230-1	460-1	380-1
Full Load Amps (each)	5.3	2.2	2.5	5.3	2.2	2.5
SYSTEM CHARACTERISTICS:						
Unit FLA	27.7	15.9	13.5	30.3	17.5	16.4
Minimum Circuit Ampacity	34	19	17	37	21	20
Max. Fuse Size or HACR						
Circuit Breaker Ampacity	50/40	25/25	20	60/45	30/25	30
Disconnect Size	60	30	25	65	35	25

NOTE: N.E.C., C.E.C. and local codes take precedence over suggested wire and fuse size.

[] Designates Metric Conversion

3.0 UNIT SPECIFICATIONS




3.2 Electrical and Physical Data (cont.)

CORNER WEIGHTS (Pounds)

UNIT MODEL	TOTAL WEIGHT LBS [kg]	CORNER WEIGHTS, LBS. [kg]			
		A	B	C	D
(-)AWL-079	245 [111]	71 [32]	54 [24]	84 [38]	36 [16]
(-)AWL-091	313 [142]	91 [41]	69 [31]	107 [49]	46 [21]

UNIT DIMENSIONS

(-)AWL	-079	-091
Height "H" Inches [mm]	45 [1143]	51 [1295]
Length "L" Inches [mm]	35.75 [908]	35.75 [908]
Width "W" Inches [mm]	35.75 [908]	35.75 [908]



ST-A1226-106-00

4.0 INSTALLATION



4.1 Tools and Refrigerant

4.1.1 Tools Required for Installing and Servicing R-410A Models

Manifold Sets:


- Up to 800 PSIG High-Side
- Up to 250 PSIG Low-Side
- 550 PSIG Low-Side Retard

Manifold Hoses:

- Service Pressure Rating of 800 PSIG

Recovery Cylinders:

- 400 PSIG Pressure Rating
- Dept. of Transportation 4BA400 or BW400



CAUTION: R-410A systems operate at higher pressures than R-22 systems. Do not use R-22 service equipment or components on R-410A equipment.

4.1.2 Specifications of R-410A

Application: R-410A is not a drop-in replacement for R-22. Equipment designs must accommodate its higher pressures. It cannot be retrofitted into R-22 heat pumps.

Physical Properties: R-410A has an atmospheric boiling point of -62.9°F [-52.7°C] and its saturation pressure at 77°F [25°C] is 224.5 psig.

Composition: R-410A is a near-azeotropic mixture of 50% by weight difluoromethane (HFC-32) and 50% by weight pentafluoroethane (HFC-125).

Pressure: The pressure of R-410A is approximately 60% (1.6 times) greater than R-22. Recovery and recycle equipment, pumps, hoses, and the like must have design pressure ratings appropriate for R-410A. *Manifold sets need to range up to 800 psig high-side and 250 psig low-side with a 550 psig low-side retard. Hoses need to have a service pressure rating of 800 psig. Recovery cylinders need to have a 400 psig service pressure rating, DOT 4BA400 or DOT BW400.*

Combustibility: At pressures above 1 atmosphere, a mixture of R-410A and air can become combustible. R-410A and air should never be mixed in tanks or supply lines or be allowed to accumulate in storage tanks. Leak checking should never be done with a mixture of R-410A and air. Leak-checking can be performed safely with nitrogen or a mixture of R-410A and nitrogen.

4.1.3 Quick-Reference Guide for R-410A

- R-410A refrigerant operates at approximately 60% higher pressure (1.6 times) than R-22. Ensure that servicing equipment is designed to operate with R-410A.
- R-410A refrigerant cylinders are light rose in color.
- R-410A, as with other HFCs, is only compatible with POE oils.
- Vacuum pumps will not remove moisture from POE oil used in R-410A systems.
- R-410A systems are to be charged with liquid refrigerants. Prior to March 1999, R-410A refrigerant cylinders had a dip tube. These cylinders should be kept upright for equipment charging. Post-March 1999 cylinders do not have a dip tube and should be inverted to ensure liquid charging of the equipment.
- Do not install a suction line filter drier in the liquid line.
- A factory-approved biflow liquid line filter drier is shipped with every unit and must be installed in the liquid line at the time of installation. Only manufacturer-approved liquid line filter driers can be used. These are Sporlan (CW083S) and Alco (80K083S) driers. These filter driers are rated for minimum working pressure of 600 psig. The filter drier will only have adequate moisture-holding capacity if the system is properly evacuated.
- Desiccant (drying agent) must be compatible for POE oils and R-410A refrigerant.

4.0 INSTALLATION



4.2 Choosing a Location

4.2.1 Allowable Clearances

12" [30.5 cm] to side intake louvers
24" [61.0 cm] between multiple units
24" [61.0 cm] to service access panels
60" [152.4 cm] vertical for fan discharge

If space limitations exist, the following clearances will have minimal impact to capacity and efficiency and are permitted:

Single-Unit Applications: Minimum of 6" [15.2 cm] to side intake louvers. Do not reduce the 60" [152.4 cm] for fan discharge or the 24" [61.0 cm] service clearances.

Multiple-Unit Applications: For units positioned next to each other, a minimum of 12" [30.5 cm] clearance between units.

Do not reduce the 60" [152.4 cm] for fan discharge or the 24" [61.0 cm] service clearances.


IMPORTANT: Consult local and national building codes and ordinances for special installation requirements. Following location information will provide longer life and simplified servicing of the outdoor unit.

NOTICE: These units must be installed outdoors. No ductwork can be attached, or other modifications made, to the discharge grille. Modifications will affect performance or operation.

4.2.2 Operational Issues Related to Unit Location

IMPORTANT: Locate the unit in a manner that will not prevent, impair, or compromise the performance of other equipment installed in proximity to the unit. Maintain all required minimum distances to gas and electric meters, dryer vents, and exhaust and inlet openings. In the absence of national codes or manufacturers' recommendations, local code recommendations and requirements will take precedence.

- Refrigerant piping and wiring should be properly sized and kept as short as possible to avoid capacity losses and increased operating costs.
- Locate the unit where water runoff will not create a problem with the equipment. Position the unit away from the drip edge of the roof whenever possible. Units are weatherized, but can be affected by the following:
- Water pouring into the unit from the junction of rooflines, without protective guttering. Large volumes of water entering the unit while in operation can impact fan blade or motor life.
- Closely follow the clearance recommendations in section 4.2.1.



4.0 INSTALLATION



4.2 Choosing a Location (cont.)

4.2.3 Corrosive Environment

The metal parts of this unit may be subject to rust or deterioration if exposed to a corrosive environment. This oxidation could shorten the equipment's useful life.

Corrosive elements include, but are not limited to, salt spray, fog or mist in seacoast areas, sulphur or chlorine from lawn watering systems, and various chemical contaminants from industries such as paper mills and petroleum refineries.

If the unit is to be installed in an area where contaminants are likely to be a problem, special attention should be given to the equipment location and exposure.

- Avoid having lawn sprinkler heads spray directly on the unit cabinet.
- In coastal areas, locate the unit on the side of the building away from the waterfront.
- Shielding provided by a fence or shrubs may give some protection, but cannot violate minimum airflow and service access clearances.

⚠ WARNING: Disconnect all power to unit before starting maintenance. Failure to do so can cause electrical shock resulting in severe personal injury or death.

Regular maintenance will reduce the buildup of contaminants and help to protect the unit's finish.

- Frequent washing of the cabinet, fan blade, and coil with fresh water will remove most of the salt or other contaminants that build up on the unit.
- Regular cleaning and waxing of the cabinet with a good automobile polish will provide some protection.
- A good liquid cleaner may be used several times a year to remove matter that will not wash off with water.

4.2.4 Customer Satisfaction Issues

- The outdoor unit should be located away from areas where noise from the unit would be considered objectionable.
- To prevent noise transmission, the mounting pad for the outdoor unit should not be connected to the structure and should be located a sufficient distance above grade to prevent ground water from entering the unit.



4.3 Mounting Unit

4.3.1 Unit Mounting Methods

The outdoor unit may be mounted in a number of ways. The most common method is on a ground mounted concrete or pre-fabricated pad. It can also be mounted on a ground or roof mounted metal frame, wooden frame, or 4" x 4" wooden stringers.

Determine if the roof and frame are structurally adequate to support the unit. If either is not structurally adequate, modifications must be made prior to installing unit.

It is extremely important to properly secure the unit to the pad or frame so it does not shift during high winds, seismic events, or other outside forces to eliminate the possibility of a safety hazard or physical damage to the unit. Local codes in regions subject to frequent hurricanes and seismic events will dictate specific mounting requirements and must be followed.

4.3.2 High Wind and Seismic Tie-Down Methods

The manufacturer-approved/recommended method is a guide to securing equipment for wind and seismic loads. Other methods might provide the same result, but the manufacturer method is the only one endorsed by the manufacturer for securing equipment where wind or earthquake damage can occur. Additional information is available on the manufacturer's website or from the wholesale distributor.

4.0 INSTALLATION


4.3.3 Elevating Unit

⚠ WARNING: Secure an elevated unit and its elevating stand in order to prevent tipping. Failure to do so may result in severe personal injury or death.

If elevating the unit, either on a flat roof or on a slab, observe the following guidelines.

- The bottom of the basepan has receptacles for 4" [10.2 cm] schedule 40 PVC pipe that can be cut to length and used as risers for slab applications.
- If elevating a unit on a flat roof, use 4" x 4" [10.2 cm x 10.2 cm] or equivalent stringers positioned to distribute unit weight evenly and prevent noise and vibration.

NOTICE: Do not block drain openings on bottom of unit.



4.0 INSTALLATION



4.4 Refrigerant Line Set Selection

4.4.1 Replacing Existing Systems

To prevent failure of a new unit, the existing line set must be correctly sized for the new unit and must be cleaned or replaced. Care must be taken so the expansion device is not plugged. For new and replacement units, a liquid line filter drier must be installed and the line set must be properly sized. Test the oil for acid. If it tests positive for acid, a suction line filter drier is mandatory.

IMPORTANT: When replacing an R-22 unit with an R-410A unit, either replace the line set or ensure that residual mineral oil is drained from existing lines including oil trapped in low spots.

4.4.2 Line Set Length and Fitting Losses

Refrigerant tubing is measured in terms of actual length and equivalent length. Actual length is used for refrigerant charge applications. Equivalent length takes into account pressure losses from

tubing length, fittings, vertical separation, accessories, and filter driers. The table below references commonly used equivalent lengths.

Table 1

Equivalent Length for Fittings (ft) [m]						
Line Size (in) [mm]	90° Short Radius Elbow	90° Long Radius Elbow	45° Elbow	Solenoid Valve	Site Glass	Filter Drier
1/2 [12.71]	1.4 [0.43]	0.9 [0.27]	0.4 [0.12]	9 [2.74]	0.6 [0.18]	6 [1.83]
5/8 [15.88]	1.5 [0.46]	1 [0.30]	0.5 [0.15]	12 [3.66]	0.8 [0.24]	6 [1.83]
3/4 [19.05]	1.9 [0.58]	1.3 [0.40]	0.6 [0.18]	14 [4.27]	N/A	N/A
7/8 [22.23]	2.3 [0.70]	1.5 [0.46]	0.7 [0.21]	15 [4.57]	N/A	N/A
1-1/8 [28.58]	2.7 [0.82]	1.8 [0.55]	0.9 [0.27]	22 [6.71]	N/A	N/A
1-3/8 [34.93]	3.6 [1.10]	2.4 [0.73]	1.2 [0.37]	28 [8.53]	N/A	N/A
1-5/8 [44.28]	4.2 [1.28]	2.8 [0.85]	1.4 [0.43]	35 [10.67]	N/A	N/A

4.4.3 Liquid Line Selection

The purpose of the liquid line is to transport warm sub-cooled liquid refrigerant between the outdoor unit to the indoor unit. It is important not to allow the refrigerant to flash into superheated vapor prior to the expansion device of the indoor coil. The flashing of refrigerant can occur for the following reasons:

- Low refrigerant charge
- Improperly selected liquid line size
- Absorption of heat prior to expansion device
- Excessive vertical separation between the outdoor unit and indoor coil
- Restricted liquid line or filter drier
- Kinked liquid line

Table 2 lists the equivalent length per 25' of liquid line at various diameters up to 250' [76 m]. The total pressure drop allowed for the liquid line is 50 PSI [345 kPa]. The procedure for selecting the proper liquid line is as follows:

- Measure the total amount of vertical separation between the outdoor unit and indoor coil.
- Measure the linear length of liquid line needed.
- Add all of the equivalent lengths associated with any fittings or accessories using Table 1 above.
- Add the linear length to the total fitting equivalent length. This will equal your total equivalent line length.
- Reference Table 2 to verify the calculated equivalent length is acceptable with the required vertical separation and diameter of liquid line.

4.0 INSTALLATION



4.4 Refrigerant Line Set Selection (cont.)

Table 2: Refrigerant Line Sizing Chart

6.5 and 7.5 Ton Single-Stage Air-Conditioners (English Units)												
Unit Size	Allowable Liquid Line Size	Allowable Suction Line Size	Equivalent Length (Feet)									
			< 25	26-50	51-75	76-100	101-125	126-150	151-175	176-200	201-225	226-250
			Maximum Vertical Rise (Outdoor Unit Below Indoor Unit) * / Capacity Multiplier									
6.5 Ton	1/2"	1-1/8"	25 / 1.00	50 / 1.00	75 / 0.99	99 / 0.99	95 / 0.99	90 / 0.98	86 / 0.98	82 / 0.97	77 / 0.97	73 / 0.97
	5/8"	1-1/8"	25 / 1.00	50 / 1.00	75 / 0.99	100 / 0.99	110 / 0.99	109 / 0.98	108 / 0.98	106 / 0.97	105 / 0.97	103 / 0.97
	1/2"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	99 / 1.00	95 / 1.00	90 / 1.00	86 / 0.99	82 / 0.99	77 / 0.99	73 / 0.99
	5/8"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	100 / 1.00	110 / 1.00	109 / 1.00	108 / 0.99	106 / 0.99	105 / 0.99	103 / 0.99
7.5 Ton	1/2"	1-1/8"	25 / 1.00	50 / 0.99	75 / 0.99	94 / 0.99	88 / 0.98	82 / 0.98	77 / 0.97	71 / 0.97	65 / 0.96	59 / 0.96
	5/8"	1-1/8"	25 / 1.00	50 / 0.99	75 / 0.99	100 / 0.99	109 / 0.98	107 / 0.98	105 / 0.97	103 / 0.97	101 / 0.96	99 / 0.96
	1/2"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	94 / 1.00	79 / 1.00	82 / 1.00	77 / 0.99	71 / 0.99	65 / 0.99	59 / 0.99
	5/8"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	100 / 1.00	109 / 1.00	107 / 1.00	105 / 0.99	103 / 0.99	101 / 0.99	99 / 0.99

6.5 and 7.5 Ton Single-Stage Air-Conditioners (Metric Units)												
Unit Size	Allowable Liquid Line Size	Allowable Suction Line Size	Equivalent Length (Meters)									
			< 8	8-15	16-23	24-30	31-38	39-46	47-53	54-61	62-69	70-76
			Maximum Vertical Rise (Outdoor Unit Below Indoor Unit) * / Capacity Multiplier									
22.86 kW [6.5 Ton]	12.7 mm [1/2"]	28.6 mm [1-1/8"]	8 / 1.00	15 / 1.00	23 / 0.99	30 / 0.99	29 / 0.99	27 / 0.98	26 / 0.98	25 / 0.97	23 / 0.97	22 / 0.97
	15.9 mm [5/8"]	28.6 mm [1-1/8"]	8 / 1.00	15 / 1.00	23 / 0.99	30 / 0.99	34 / 0.99	33 / 0.98	33 / 0.98	32 / 0.97	32 / 0.97	31 / 0.97
	12.7 mm [1/2"]	34.9 mm [1-3/8"]	8 / 1.00	15 / 1.00	23 / 1.00	30 / 1.00	29 / 1.00	27 / 1.00	26 / 0.99	25 / 0.99	23 / 0.99	22 / 0.99
	15.9 mm [5/8"]	34.9 mm [1-3/8"]	8 / 1.00	15 / 1.00	23 / 1.00	30 / 1.00	34 / 1.00	33 / 1.00	33 / 0.99	32 / 0.99	32 / 0.99	31 / 0.99
26.38 kW [7.5 Ton]	12.7 mm [1/2"]	28.6 mm [1-1/8"]	8 / 1.00	15 / 0.99	23 / 0.99	29 / 0.99	27 / 0.98	25 / 0.98	23 / 0.97	22 / 0.97	20 / 0.96	18 / 0.96
	15.9 mm [5/8"]	28.6 mm [1-1/8"]	8 / 1.00	15 / 0.99	23 / 0.99	30 / 0.99	33 / 0.98	33 / 0.98	32 / 0.97	31 / 0.97	31 / 0.96	30 / 0.96
	12.7 mm [1/2"]	34.9 mm [1-3/8"]	8 / 1.00	15 / 1.00	23 / 1.00	29 / 1.00	27 / 1.00	25 / 1.00	23 / 0.99	22 / 0.99	20 / 0.99	18 / 0.99
	15.9 mm [5/8"]	34.9 mm [1-3/8"]	8 / 1.00	15 / 1.00	23 / 1.00	30 / 1.00	33 / 1.00	33 / 1.00	32 / 0.99	31 / 0.99	31 / 0.99	30 / 0.99

Notes:

- 1) Do not exceed 200 ft [61 meters] linear line length.
- 2) * Do not exceed 100 ft [30 meters] vertical separation if outdoor unit is above indoor unit.
- 3) Always use the smallest liquid line allowable to minimize refrigerant charge.
- 4) Applications shaded in light gray indicate capacity multipliers between 0.90 and 0.96 which are not recommended, but are allowed.

Example: A 7.5 ton condensing unit is installed 50' below the indoor unit, requires 75' of 1/2" diameter liquid line, 1-1/8" diameter suction line, and 4 90° LR elbows, and a filter drier.

This application is acceptable because the 50' vertical rise is less than the maximum rise of 94' for this application.

- Filter Drier Equivalent Length (ft.) = 6'
- Fitting Equivalent Length (ft.) = 4 × 0.9' = 3.6'
- Total Equivalent Length (ft.) = 75' + 6' + 3.6' = 84.6'

Unit Size	Allowable Liquid Line Size	Allowable Suction Line Size	Equivalent Length (Feet)									
			< 25	26-50	51-75	76-100	101-125	126-150	151-175	176-200	201-225	226-250
			Maximum Vertical Rise (Outdoor Unit Below Indoor Unit) * / Capacity Multiplier									
7.5 Ton	1/2"	1-1/8"	25 / 1.00	50 / 0.99	75 / 0.99	94 / 0.99	88 / 0.98	82 / 0.98	77 / 0.97	71 / 0.97	65 / 0.96	59 / 0.96
	5/8"	1-1/8"	25 / 1.00	50 / 0.99	75 / 0.99	100 / 0.99	109 / 0.98	107 / 0.98	105 / 0.97	103 / 0.97	101 / 0.96	99 / 0.96
	1/2"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	94 / 1.00	79 / 1.00	82 / 1.00	77 / 0.99	71 / 0.99	65 / 0.99	59 / 0.99
	5/8"	1-3/8"	25 / 1.00	50 / 1.00	75 / 1.00	100 / 1.00	109 / 1.00	107 / 1.00	105 / 0.99	103 / 0.99	101 / 0.99	99 / 0.99

(Excerpt from Table 2)

4.0 INSTALLATION



4.4 Refrigerant Line Set Selection (cont.)

4.4.4 Suction Line Selection

Purpose of the vapor line is to return superheated vapor to the condensing unit from the evaporator. Proper suction line sizing is important because it plays an important role in returning oil to the compressor to prevent potential damage to the bearings, valves, and scroll sets. Also, an undersized suction line can dramatically reduce capacity and performance of the system. The procedure for selecting the proper suction line is as follows:

- Determine the total linear length of suction line required.
- Add all of the equivalent lengths associated with any fittings or accessories using the table on previous page.
- Add the linear length and total fitting equivalent length. This will equal your total equivalent length.
- Reference Table 2 to verify that the calculated equivalent length falls within the acceptable region of the chart.
- Verify the capacity difference is compatible with the application using the multiplier in Table 2.
- Use only suction line sizes listed in Table 2.

4.4.5 Long Line Set Considerations

Generally, installations with actual (linear) line set lengths over 80 ft. [24 m] or vertical separation between the outdoor and indoor units exceed 20 ft. [6 m] are considered long line length applications and require special considerations to maintain good performance and compressor reliability. The following things should be considered when installing a system with a long line set length.

- Additional refrigerant charge
- Fitting losses and maximum equivalent length considerations
- Refrigerant migration during the off cycle
- Oil return to the compressor
- Capacity losses
- Additional oil

4.4.5.1 Oil Return to Compressor

Small amounts of compressor crankcase oil is picked up and carried out of the compressor by the moving refrigerant and is circulated through the system along with the refrigerant before it returns to the compressor crankcase. It is critical to the life of the compressor for the oil to be able to return to the compressor to maintain an adequate level of oil in the compressor crankcase. Oversized vapor lines result in inadequate refrigerant velocities

to carry the oil along with the refrigerant and will cause the oil to accumulate in the low spots in the vapor line instead of being returned to the compressor crankcase. This is especially true for long line lengths. Only use the vapor line sizes listed in Table 2 to assure proper oil return. Do not oversize the vapor line.

4.4.5.2 Refrigerant Migration During Off Cycle

Long line set applications can require a considerable amount of additional refrigerant. This additional refrigerant must be managed throughout the entire outdoor ambient operating range that the system will experience throughout its life cycle. Off-cycle refrigerant migration is where refrigerant condenses and migrates to the coldest and/or lowest part of the system. Excessive build-up of refrigerant near or inside the compressor can result in poor reliability and noisy operation during start-up. Long line set applications require a non-bleed TXV on the indoor coil and a crankcase heater. All models related to this manual have a crankcase heater from the factory and all AHRI matched indoor units have a non-bleed TXV. If only the condensing unit is being replaced, it is important to confirm that the indoor coil has a non-bleed TXV. If it doesn't, a liquid line solenoid valve must be installed near the indoor coil with the flow arrow pointing toward the indoor coil.

4.4.5.3 Maximum Liquid Pressure Drop

The total liquid line pressure drop must not exceed 50 psig [345 kPa] to assure a solid column of liquid at the metering device and stable control of superheat. Be sure to account for vertical separation, elbows, filter driers, solenoid valves, sight glasses, and check valves when calculating liquid line pressure drop.

4.4.5.4 Liquid Line Refrigerant Flashing

Excessive pressure drop and heat gain in long liquid lines can result in the refrigerant flashing into a vapor before it reaches the metering device which will dramatically reduce the capacity and efficiency of the system. For this reason, the liquid line must be sized properly using Table 2 and must be insulated in unconditioned spaces.

4.0 INSTALLATION



4.4 Refrigerant Line Set Selection (cont.)

4.4.5.5 Compressor Oil Level Adjustment

Additional oil will need to be added for long line set applications. Below is the equation for the oil level adjustment. The compressor name plate oil charge for the different outdoor units is shown in the table below.

Oil to be Added = [(Charge Adjustment + OD Unit Name Plate Charge (oz.)) × (0.022) – [(0.10) × (Compressor Name Plate Oil Charge (oz.))]

Example: An application requires 125 ft. of line set with a liquid line diameter of 3/8", Charge Adjustment = 52.4 oz., Name Plate Charge = 107 oz., Name Plate Oil Charge = 25 oz., Oil to be Added = ((52.4 oz. + 107 oz.) × .022) – (.10 × 25 oz.) = 1.0 oz.

Unit Model	Compressor Nameplate Oil Charge
(-)AWL-079	56 fl. oz. [1656 ml]
(-)AWL-091	60 fl. oz. [1774 ml]

4.4.5.6 Capacity Losses


Long line lengths can result in a reduction in capacity due to suction line pressure drop and heat gain. Refer to Table 2 for capacity loss multipliers for various vapor line diameters and lengths. Only use vapor lines listed in Table 2 to assure proper oil return. This table does not account for any capacity loss due to heat gain from the environment. It is extremely important not to oversize the suction line to minimize capacity loss at the expense of proper oil return. The full length of the suction line must be insulated to minimize heat gain.

4.0 INSTALLATION



4.5 Line Set Installation


- If tubing is to be run underground, it must be run in a sealed watertight chase.
- Use care in routing tubing and do not kink or twist. Use a good quality tubing bender on the vapor line to prevent kinking.



- Route the tubing using temporary hangers; then straighten the tubing and install permanent hangers. The tubing must be adequately supported.
- Isolate the vapor line from the building structure. If the vapor line comes in contact with inside walls, ceiling, or flooring, the vibration of the vapor line

in the heating mode will result in noise inside the structure.


- Blow out the liquid and vapor lines with dry nitrogen before connecting to the outdoor unit and indoor coil to remove debris that can plug the expansion device.



4.5.1 Important Tubing Installation Practices

Observe the following when installing correctly sized type “L” refrigerant tubing between the outdoor unit and indoor coil:

- Check Table 2 for the correct suction line size and liquid line size.
- **If a portion of the liquid line passes through a very hot area where liquid refrigerant can be heated to form vapor, insulating the liquid line is required.**
- Use clean, dehydrated, sealed refrigeration-grade tubing.
- Always keep tubing sealed until tubing is in place and connections are to be made.
- A high-quality filter drier is included with all units and must be installed in the liquid line upon unit installation.
- When replacing an R-22 system with an R-410A system and the line set is not replaced, blow out the lines with dry nitrogen to remove as much of the remaining mineral oil as possible. Check for low spots where oil may be trapped and take measures to drain the oil from those areas.



- If tubing has been cut, debur the ends while holding the tubing in a position to prevent chips from falling into tubing. Burrs such as those caused by tubing cutters can affect performance dramatically, particularly on small diameter liquid lines.
- For best operation, keep tubing run as short as possible with a minimum number of elbows or bends.
- Locations where the tubing will be exposed to mechanical damage should be avoided. If it is necessary to use such locations, the copper tubing should be protected by a housing to prevent damage.


4.0 INSTALLATION



4.5 Line Set Installation (cont.)

4.5.2 Relative Location of Indoor and Outdoor Units

4.5.2.1 Indoor and Outdoor Unit Near Same Level



For applications that are considered to have a long line set with the outdoor unit and indoor unit near the same level the following is required:


- Non-bleed TXV on the indoor coil or install liquid line solenoid valve near indoor unit with flow arrow pointing toward indoor unit.
- Insulated liquid line in unconditioned space only. Insulated suction line full length.
- Suction line should slope toward the indoor unit
- Follow the proper line sizing, maximum linear and equivalent lengths, charging requirements, and oil level adjustments spelled out in this manual.
- Verify at least 5°F [2.8°C] liquid sub-cooling at the indoor unit prior to expansion device.

4.0 INSTALLATION



4.5 Line Set Installation (cont.)

4.5.2.2 Outdoor Unit Below Indoor Unit



For applications that are considered to have a long line set with the outdoor unit below the indoor unit the following is required:


- Non-bleed TXV or at the indoor coil or install liquid line solenoid valve near indoor unit with flow arrow pointing toward indoor unit.
- Refrigerant lines should be routed even with the top of the indoor coil or an inverted trap is to be applied (refer to above illustration).
- Insulated liquid line in unconditioned space only.
- Insulated suction line full length.
- Follow the proper line sizing, maximum linear and equivalent lengths, charging requirements, and oil level adjustments spelled out in this manual.
- Verify at least 5°F [2.8°C] liquid sub-cooling at the indoor unit prior to expansion device.
- Vertical separations greater than 25' [7.62 m] can expect a lower sub-cooling level.

4.0 INSTALLATION



4.5 Line Set Installation (cont.)

4.5.2.3 Outdoor Unit Above Indoor Unit



For applications that are considered to have a long line set with the outdoor unit above the indoor unit the following is required:

- Non-bleed TXV on the indoor coil or install liquid line solenoid valve near indoor unit with flow arrow pointing toward indoor unit.
- Insulated liquid line in unconditioned space only. Insulated suction line full length.

- Follow the proper line sizing, maximum linear and equivalent lengths, charging requirements, and oil level adjustments spelled out in this manual.

4.0 INSTALLATION




4.5 Line Set Installation (cont.)


4.5.3 Tubing Connections

Indoor coils have only a holding charge of dry nitrogen. Keep all tube ends sealed until connections are to be made.


- Use type “L” copper refrigeration tubing. Braze the connections with the following alloys:
 - Copper to copper, 5% silver minimum
 - Copper to steel or brass, 15% silver minimum



- Be certain both refrigerant shutoff valves at the outdoor unit are closed.




- Remove the caps and Schrader cores from the pressure ports to protect seals from heat damage. Both the Schrader valves and the service valves have seals that may be damaged by excessive heat.




- Clean the inside of the fittings and outside of the tubing with a clean, dry cloth before soldering. Clean out debris, chips, dirt, etc., that enters tubing or service valve connections.


NOTE: Service valves and pressure port locations may be slightly different than shown in illustrations.




- Wrap valves with a wet rag or thermal barrier compound before applying heat.



- Braze the tubing between the outdoor unit and indoor coil. Flow dry nitrogen into a pressure port and through the tubing while brazing, but do not allow pressure inside tubing which can result in leaks. Once the system is full of nitrogen, the nitrogen regulator should be turned off to avoid pressuring the system.



- After brazing, use an appropriate heatsink material to cool the joint.
- Reinstall the Schrader cores into both pressure ports.




- Do not allow the bare suction line and liquid line to be in contact with each other. This causes an undesirable heat transfer resulting in capacity loss and increased power consumption.

4.0 INSTALLATION


4.6 Initial Leak Testing

Indoor coils have only a holding charge of dry nitrogen. Keep all tube ends sealed until connections are to be made.

⚠WARNING: Do not use oxygen to purge lines or pressurize system for leak test. Oxygen reacts violently with oil, which can cause an explosion resulting in severe personal injury or death.



- Pressurize line set and coil through service fittings with dry nitrogen to a maximum of 150 PSIG [1034 kPa]. Close nitrogen tank valve, let system sit for at least 15 minutes, and check to see if the pressure has dropped. If the pressure has dropped, check for leaks at the line set braze joints with soap bubbles and repair leak as necessary. Repeat pressure test. If line set and coil hold pressure, proceed with line set and coil evacuation (see Sections 4.7 and 4.8 for evacuation and final leak testing).




- The suction line must be insulated for its entire length to prevent dripping (sweating) and prevent performance losses. Closed-cell foam insulation such as Armaflex and Rubatex® are satisfactory insulations for this purpose. Use 1/2" [12.7 mm] minimum insulation thickness. Additional insulation may be required for long runs. The liquid line must be insulated in any unconditioned space when long line sets are used and anytime the liquid line is run through an attic due to hot temperatures that occur there.

4.7 Evacuation

Evacuation is one of the most important parts of the entire installation and service procedure. The life and efficiency of the equipment is dependent upon the thoroughness exercised by the serviceman when evacuating air and moisture from the system.

Air or nitrogen in the system increases condensing temperature and pressure, resulting in increased power consumption, erratic operation, and reduced capacity.

Moisture chemically reacts with the refrigerant and oil to form corrosive acid which attacks the compressor motor windings and internal parts and which can result in compressor failure.



IMPORTANT: The outdoor units are shipped with a nitrogen holding charge and must be evacuated along with the line set and indoor coil.

After the system has been leak-checked and proven leak free, open both outdoor unit service valves and connect the vacuum pump to the hose from the middle port of the manifold gauge set. Connect the high and low side hoses to the service ports on both service valves. Open both valves on the gauge set completely before starting the vacuum pump. Evacuate system to 500 microns and hold 500 microns or less for at least 15 minutes. Use the largest size connections available since restrictive service connections may lead to false readings because of pressure drop through the fittings.

4.0 INSTALLATION



4.8 Control Wiring

⚠ WARNING: Turn off electric power at the fuse box or service panel before making any electrical connections. Also, the ground connection must be completed before making line voltage connections. Failure to do so can result in electrical shock, severe personal injury, or death.

Running low-voltage wires in conduit with line voltage power wires is not recommended. Low-voltage wiring is to be connected to the pigtails hanging down from the bottom of the control box.

A thermostat and a 24-volt, 50 VA minimum transformer are required for the control circuit of the system. A 50 VA transformer is supplied in the outdoor unit from the factory. See the wiring diagram for reference. Use "Wire Size" guide below to size the 24-volt control wiring.

Do not use phone cord to connect indoor and outdoor units and thermostat. This could damage the controls and may not be adequately sized for the control's electrical load.

FIELD WIRE SIZE FOR 24-VOLT THERMOSTAT CIRCUITS:

Runs up to 100 ft [30.5 m]: 18 AWG


Runs over 100 ft [30.5 m]: 16 AWG

NOTICE: Do not use control wiring smaller than No. 18 AWG between thermostat and outdoor unit.



4.9 Typical Field Wiring Connections

The following diagram shows the typical wiring connections for a single-stage condensing unit and an air-handler with electric heat.



4.0 INSTALLATION



4.10 Configuring Control Transformer for 208V Applications

The control transformer supplied with 208/230V models is factory wired for 230V applications and must be reconfigured for 208V applications upon installation by disconnecting the Orange transformer primary lead from the compressor contactor L1 terminal and connecting the Red transformer primary lead to the compressor L1 terminal. The Orange and Red transformer primary lead terminals are insulated to prevent the disconnected lead from shorting to ground, but the terminal on the disconnected Orange transformer lead should still be secured with a wire tie so it is isolated from ground as to assure it cannot come in contact with a grounded surface and short the transformer out.


4.11 Power Wiring

It is important that proper electrical power from a commercial utility is available at the outdoor unit contactor. Voltage ranges for operation are shown below.


VOLTAGE RANGES (60 HZ)

Nameplate Voltage	Operating Voltage Range at Maximum Load Design Conditions for Compressors
208/230	187 - 253
380/415	342 - 457
460	414 - 506
575	517 - 633

Install a branch circuit disconnect within sight of the unit and of adequate size to handle the minimum circuit capacity (see Section 3.2).



Power wiring must be run in a rain-tight conduit. Conduit must be run through the connector panel below the access cover (see illustration in section 3.2) and attached to the bottom of the control box as shown below.



ST-A1226-09


Connect power wiring to line-voltage lugs located in the unit electrical box. (See wiring diagram attached to unit access panel and above illustration.)

Check all electrical connections, including factory wiring within the unit and make sure all connections are tight.

DO NOT connect aluminum field wire to the contactor terminals.

4.12 Grounding

⚠ WARNING: The unit must be permanently grounded. Failure to do so can cause electrical shock resulting in severe personal injury or death.



ST-A1226-09

A grounding lug is provided near the line-voltage power entrance for a ground wire as shown in the above illustration.

5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.1 Start-Up Overview

Once the system hardware and wiring have been properly installed and the system has been properly evacuated, the next step is to weigh in the preliminary refrigerant charge and conduct a final leak check before applying electrical power and starting the system.


When the system is first started, indoor blower motor rotation, compressor rotation, and indoor air-flow, must be verified prior to the refrigerant charge being finalized using pressures and the charging chart attached to the inside of the control box cover.

To achieve optimum system reliability and comfort, it is important to follow the procedures in the following sections to assure the indoor air-flow and the refrigerant charge are correct.

CAUTION: R-410A pressures are approximately 60% higher (1.6 times) than R-22 pressures. Use appropriate care when using this refrigerant. Failure to exercise care may result in equipment damage or personal injury.

IMPORTANT: Both the outdoor and indoor units are shipped with a nitrogen holding charge. Starting the system prior to evacuating the system and adding refrigerant or while system is in a vacuum will result in damage to the compressor.

IMPORTANT: After the preliminary refrigerant charge has been weighed in, it is recommended that the electrical power be applied to the outdoor unit for 12 hours before the compressor is started to allow the crankcase heater to drive any liquid refrigerant from the compressor shell.



5.2 Preliminary Charging by Weight and Final Leak Check

After the system has been properly evacuated, close the valves on the manifold gauge set and disconnect the vacuum pump. Connect the center hose from the manifold gauge set to the R-410a refrigerant tank. Open the valve on the refrigerant tank and then loosen the hose at the gauge set slightly to purge the air from the hose, then retighten the hose at the gauge set. Invert the refrigerant tank and place it on an accurate weight scale (+/- 1 oz [28.3g]). Inverting the refrigerant tank will direct only liquid refrigerant to the unit.

IMPORTANT: R-410A is a blended refrigerant of R-32 and R-125. These two refrigerants have different saturation curves and therefore change state at different pressures and temperatures. If charge is added to the system in the vapor stage, it is possible to have a disproportionate amount of R-32 and R-125 which will cause unstable and inefficient operation. Therefore, it is critical to add R-410A in the liquid form only.

Refer to the basic system charge from the unit data plate (or table below) and add to that the required weight of refrigerant for the line set length. Calculate the total preliminary refrigerant charge using the following tables and formulas.

REQUIRED OZS. R-410A PER FT. OF TUBING

Tube Size O.D., In. [mm]	Liquid oz/ft [g/m]	Vapor oz/ft [g/m]
1/2 [12.7]	1.06 [100.5]	0.04 [3.7]
5/8 [15.9]	1.65 [153.5]	0.07 [6.5]
3/4 [19.1]	2.46 [228.8]	0.10 [9.3]
7/8 [22.2]	3.28 [305.1]	0.13 [12.1]
1 1/8 [28.6]		0.22 [20.5]
1 3/8 [34.9]		0.34 [31.6]
1 5/8 [41.3]		0.48 [44.7]
2 1/8 [54.0]		0.84 [78.1]

Quantities based on 110°F liquid and 45°F vapor.

BASIC SYSTEM CHARGE*

Unit Model	Basic System Charge, Oz. [g] *
(-)AWL-079	219 [6,209]
(-)AWL-091	400 [11,340]

*-System with 0 Feet [0] of tubing.

Start-Up

Airflow

5.0 SYSTEM START-UP & REFRIGERANT CHARGING

Charge Adjustment = Total Linear Line Length x (oz/ft or g/m for liquid line + oz/ft or g/m for suction line)

Preliminary Refrigerant Charge = Basic System Charge + Charge Adjustment

Example: A 7.5 ton system requires 75 ft. of line set with a 1/2" liquid line and 1-1/8" suction line.

Charge Adjustment = 75 ft. x (1.06 oz/ft + 0.22 oz/ft) = 75 ft. x 1.28 oz/ft. = 96 oz

Basic Refrigerant Charge = 400 oz

Preliminary Refrigerant Charge = 400 oz + 96 oz = 496 oz

Open the high side valve of the manifold gauge set and allow as much refrigerant to flow into the high side of the system as possible up to the preliminary refrigerant charge. Then open the low side valve of the manifold gauge set and finish weighing in the preliminary refrigerant charge. If the system will not take the entire preliminary charge, the remaining amount of charge can be added once the outdoor unit is started up.

Close both valves on the manifold gauge set and conduct a final leak check on all of the braze joints between the indoor and outdoor units using a halogen leak detector. If a leak is detected, the refrigerant must be recovered before repairing the leak. The Clean Air Act prohibits releasing refrigerant into the atmosphere.

5.3 Pre-Start Check

Start-Up

<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	1.	Is condensing unit properly located and level?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	2.	Is air free to travel to and from condensing unit?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	3.	Is the wiring correct and according to the unit wiring diagram?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	4.	Are wiring connections tight? (including those in unit and compressor electrical box.)
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	5.	Is the unit properly grounded?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	6.	Is circulating air blower correctly wired?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	7.	Is condensing unit properly fused?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	8.	Is the thermostat level, correctly wired and in good location?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	9.	Is the ductwork correctly sized, run, taped and insulated?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	10.	Is refrigerant tubing neatly run and vapor line thoroughly insulated?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	11.	Is condensate drain line properly sized, run, tapped and pitched?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	12.	Are refrigerant connections tight and leak tested?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	13.	Is filter clean and in place?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	14.	Does the condenser fan turn free without rubbing?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	15.	Is the fan tight in the fan shaft?
<input type="checkbox"/>	YES	<input type="checkbox"/>	NO	16.	Are all covers and access panels in place to prevent air loss?

5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.4 Initial System Start-Up: Verifying Correct Indoor Blower Motor and Compressor Rotation.


After the refrigerant charge is weighed in, it is recommended that electrical power be applied to both the indoor and outdoor units for a minimum of 12 hours with the thermostat turned to the OFF position to give the crankcase heater time to drive liquid refrigerant from the compressor shell. After 12 hours, the thermostat may be adjusted to call for the cooling mode. It is very important at this point to verify that the indoor blower motor rotation (3-phase air-handlers) and compressor rotation are both correct to prevent damage to the compressor.

- If the 3-phase indoor blower is turning backwards (blower turning, but no air-flow), shut the electrical power off to the indoor and outdoor units and reverse two incoming line voltage leads to the air-handler. Restore electrical power to the indoor and outdoor units and verify the indoor blower motor rotation is correct and air is flowing through the ductwork.
- Check to make sure the liquid pressure increases and the suction pressure decreases when the compressor first starts, indicating the compressor rotation is correct. If there is no pressure differential and the compressor is making a loud rattling sound, shut the electrical power off to the outdoor unit and reverse two of the incoming power leads at the outdoor unit contactor. Restore electrical power to the outdoor unit and confirm the liquid pressure increases the suction pressure decreases, and the compressor is operating at a normal sound level.

Note: The outdoor fan motor is a single phase motor and will therefore always have the correct rotation regardless of how the electrical power is connected to the contactor.

5.5 Verifying Indoor Air-Flow

Before final refrigerant charge adjustment, the indoor air-flow must be verified and adjusted if necessary. Adjust the thermostat set point so the indoor air-handler or furnace operates in the cooling air-flow mode. Some air-handlers and furnaces deliver a different air-flow level for continuous fan operation, so it is important to verify the indoor air-flow while the thermostat is set to operate in the cooling mode. Determine the rated indoor air-flow by referring to the AHRI Directory, manufacturer's specifications, or engineer's specification for the matched system. If this information is not available, 350 - 400 CFM per ton is a good rule of thumb. Refer to the air-handler or gas furnace installation and operation manual for air-flow tables and for adjusting the cooling mode indoor air-flow. External static pressure will need to be measured and used for this adjustment. For furnace/coil combinations, the coil pressure drop is considered part of the external static pressure to the furnace. An air velocity meter or air-flow hood can also give an accurate reading for indoor air-flow.



5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.6 Final Charging by Pressures

1) Once the indoor air-flow is verified, operate the system for a minimum of 15 minutes in the cooling mode prior to checking pressures and the outdoor ambient temperature.

IMPORTANT: Indoor conditions must be within 2°F [1.1°C] of comfort conditions per the building manager's preference for final refrigerant charging. If the indoor temperature is above or below this range, continue running the system in the cooling mode or run the furnace or electric heat to bring the temperature to within this range.

2) Locate the system charging chart on the inside of the control box cover or in Section 5.7 of this manual.

3) Note the Outdoor Dry Bulb Temperature, Suction (Vapor) Pressure, and Liquid Pressure.

4) Find the intersection of the Suction (Vapor) Pressure on the appropriate Outdoor Ambient Temperature line and note the Liquid Pressure on the chart. If the outdoor ambient is between two of the outdoor ambient lines on the chart, estimate the liquid pressure as required.


5) If the measured liquid pressure is below the liquid pressure indicated on the charging chart, add refrigerant to the system. If the measured liquid pressure is above the liquid pressure indicated on the charging chart, remove refrigerant from the system. Allow the system to stabilize for 5 minutes before rechecking the pressures against the chart.

6) Repeat steps 4 and 5 as required.

7) Once the pressures are correct, allow the system to operate for a minimum of 15 minutes and recheck the pressures against the charging chart, adjust charge as needed, and repeat until the pressures are correct after 15 minutes of operating at that charge level.

5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.7 CHARGING CHARTS




5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.7 CHARGING CHARTS

7.5 TON CONDENSING UNIT 60 HZ (R410A) A/C SYSTEM CHARGE CHART

CAUTION:
RETURN AIR TEMPERATURE MUST BE WITHIN COMFORT
CONDITIONS BEFORE FINAL REFRIGERANT CHECK!



INSTRUCTIONS:

1. MEASURE PRESSURE AT COMPRESSOR SUCTION AND LIQUID.
2. MEASURE OUTDOOR AMBIENT TO UNIT.
3. PLACE AN "X" ON THE CHART WHERE THE SUCTION AND LIQUID INTERSECT.
4. IF "X" IS BELOW OUTDOOR AMBIENT TEMPERATURE LINE, ADD CHARGE AND REPEAT STEPS 1-3.
5. IF "X" IS ABOVE AMBIENT TEMPERATURE LINE, RECOVER EXCESS CHARGE AND REPEAT STEPS 1-3.

92-102644-18-02

5.0 SYSTEM START-UP & REFRIGERANT CHARGING

5.8 Completing Installation

- Disconnect the hoses from the pressure ports. Replace the pressure port caps and tighten adequately to seal caps. **Do not overtighten.**
- Replace the service valve top caps finger-tight and then tighten with a wrench to adequately seal caps. **Do not overtighten.**
- Replace control box cover and service panel and install screws to secure panels.
- Restore power to unit at disconnect if required.
- Configure thermostat per the thermostat installation instructions and set to desired mode and temperature.

6.0 SEQUENCE OF OPERATION

When the thermostat calls for cooling, the compressor contactor contacts close and energize, the compressor and outdoor fan motor and the system provides cooling and dehumidification for the conditioned space. When the thermostat call for cooling is satisfied or turned to the off position, the compressor contactor contacts open and the compressor and outdoor fan motor are de-energized. If the high or low pressure switch contacts are open the compressor contactor contacts will open and the compressor and outdoor fan motor will be de-energized until the pressure is such that the pressure switch contacts close.

7.0 COMPONENTS & CONTROLS

7.1 Compressor

Single-stage 3-Phase scroll compressors are used in all models.

7.2 Fan Motor

All models utilize a high efficiency single-speed ECM motor.

7.3 Outdoor Fan


All models utilize a 3 blade swept blade fan made from aluminum.

7.4 Compressor Contractor

All models utilize a 3-pole contactor to power the compressor and fan motor. Field power is connected directly to the terminal lugs on the line side of the contactor.

7.5 Compressor Crankcase Heat (CCH)

All models are equipped with a 70 watt belly-band style crankcase heater that is energized anytime electrical power is supplied to the unit.



All heaters are located on the lower half of the compressor shell. Its purpose is to drive refrigerant from the compressor shell during long off cycles, thus preventing damage to the compressor during start-up.

At initial start-up or after extended shutdown periods, make sure the heater is energized for at least 12 hours before the compressor is started. (Disconnect switch is on and wall thermostat is off.)

7.6 High- and Low-Pressure Controls (HPC and LPC)

High and low pressure controls are standard on all models.

The high-pressure control (HPC) is an automatic-reset which opens near 610 PSIG [4206 kPa] and closes near 420 PSIG [2896 kPa].

The low-pressure control (LPC) is an automatic-reset which opens near 50 PSIG [345 kPa] and closes near 95 PSIG [655 kPa].

⚠ CAUTION: The compressor has an internal overload protector. Under some conditions, it can take up to 2 hours for this overload to reset. Make sure overload has had time to reset before condemning the compressor.

7.7 Transformer

A 50VA transformer is provided inside the unit control box for supplying 24VAC for both the outdoor and indoor unit control system. 208V applications require the transformer to be reconfigured upon installation (See Section 4.11).


8.0 ACCESSORIES

⚠WARNING: Turn off electric power at the fuse box or service panel before making any electrical connections while installing accessories. Failure to do so can result in electrical shock, severe personal injury, or death.

8.1 Compressor Time Delay

The time delay (TDC) is in the low voltage control circuit. When the compressor shuts off due to a power failure or thermostat operation, this control keeps it off at least 5 minutes before the next cycle can begin.

Part No. **RXAT-A01**



8.2 Low Ambient Control

This component senses compressor head pressure and shuts the heat pump fan off when the head pressure drops to approximately 250 PSIG. This allows the unit to build a sufficient head pressure at lower outdoor ambient (down to 0°F [-18°C]) in order to maintain system balance and capacity. Low ambient control should be used on all equipment frequently operated below 70°F [21°C] ambient. Part No. **RXAD-A08**

8.3 Compressor Sound Enclosure

Part No. **68-25217-10**

8.4 Liquid Line Solenoid Valve (24V)

Recommended for all split system applications without a non-bleed TXV on the indoor coil, to prevent refrigerant migration during off cycles. Solenoid valve is to be located in liquid line near air handler.

Part No. **RXAV-CD078**


8.5 Sight Glass

SIGHT GLASS — Allows viewing of the refrigerant. Bubbles may indicate a shortage of refrigerant or a restriction in the liquid line. The color indicator shows relative moisture saturation of the refrigerant. Its inclusion in the refrigerant piping is recommended. A minimum of 12 hours after installation is required before attempting to determine if a moisture condition within the system exists.

Part No. **RXAG-A048**

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.1 Cooling Mechanical Checks Flowchart



9.0 DIAGNOSTICS & TROUBLESHOOTING

9.2 General Troubleshooting Guide

⚠ WARNING: Disconnect all power to unit before servicing. Contactor may break only one side. Failure to shut off power can cause electrical shock resulting in personal injury or death.

SYMPTOM	POSSIBLE CAUSE	REMEDY
Unit will not run	<ul style="list-style-type: none"> Power off or loose electrical connection Thermostat out of calibration – set too low or high Blown fuses/tripped breaker Transformer defective High-pressure control open Low pressure control open Miswiring of thermostat 	<ul style="list-style-type: none"> Check for correct voltage at line voltage connections in condensing unit. Adjust thermostat. Replace fuses/reset breaker. Check wiring. Replace transformer. See high head pressure remedy. See low suction pressure remedy. Check thermostat wiring.
Outdoor fan runs, compressor doesn't	<ul style="list-style-type: none"> Loose connection Compressor stuck, grounded or open motor winding, open internal overload. 	<ul style="list-style-type: none"> Check for correct voltage at compressor. Check and tighten all connections. Wait at least 3 hours for overload to reset. If still open, replace the compressor.
Insufficient cooling	<ul style="list-style-type: none"> Improperly sized unit Improper indoor airflow Incorrect refrigerant charge Air, noncondensibles, or moisture in system Restricted refrigerant circuit 	<ul style="list-style-type: none"> Recalculate building load. Check. Should be approximately 350-400 CFM [165-189 L/s] per ton. Charge per procedure attached to unit service panel. Recover refrigerant. Evacuate and recharge. Locate restriction and clear. Add or replace filter drier.
Compressor short cycles	<ul style="list-style-type: none"> Incorrect voltage Defective overload protector Refrigerant undercharge or overcharge (HPC or LPC cycling) 	<ul style="list-style-type: none"> At compressor terminals, voltage must be $\pm 10\%$ of nameplate marking when unit is operating. Replace compressor. Check for correct voltage. Adjust charge per charging chart.
Registers sweat	<ul style="list-style-type: none"> Low indoor airflow 	<ul style="list-style-type: none"> Increase speed of blower or reduce restriction. Replace air filter.
High head, low suction pressures	<ul style="list-style-type: none"> Restriction in liquid line, expansion device, or filter drier Bad TXV 	<ul style="list-style-type: none"> Remove or replace defective component. Replace TXV.
High head, high or normal suction pressure	<ul style="list-style-type: none"> Dirty outdoor coil Refrigerant overcharge Outdoor fan not running Air or noncondensibles in system 	<ul style="list-style-type: none"> Clean coil. Correct system charge. Repair or replace. Recover refrigerant. Evacuate and recharge.
Low head, high vapor pressures	<ul style="list-style-type: none"> Bad TXV Bad compressor 	<ul style="list-style-type: none"> Replace TXV. Replace compressor.
Low suction pressure, iced indoor coil	<ul style="list-style-type: none"> Low indoor airflow Operating below 65°F [18°C] outdoors Moisture in system Low refrigerant charge 	<ul style="list-style-type: none"> Increase speed of blower or reduce restriction. Replace air filter. Add Low Ambient Kit. Recover refrigerant. Evacuate and recharge. Add filter drier. Check refrigerant charge and check for leaks.
High suction pressure	<ul style="list-style-type: none"> Excessive load Defective compressor 	<ul style="list-style-type: none"> Recheck load calculation. Replace.
Fluctuating head and suction pressures	<ul style="list-style-type: none"> TXV hunting Air or noncondensibles in system 	<ul style="list-style-type: none"> Check TXV bulb clamp. Check air distribution on coil. Replace TXV. Recover refrigerant. Evacuate and recharge.
Gurgle or pulsing noise at expansion device or liquid line	<ul style="list-style-type: none"> Air or noncondensibles in system Undercharged system 	<ul style="list-style-type: none"> Recover refrigerant. Evacuate and recharge. Adjust charge per charging chart.

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.3 Service Analyzer Charts

COMPRESSOR OVERHEATING		
SYMPTOM	POSSIBLE CAUSE	CHECK/REMEDY
High superheat (greater than 15°F [8.3°C] at coil)	Low charge	Check system charge.
	Faulty metering device	Restricted cap tube, TXV
		Power element superheat out of adjustment internally
		Foreign matter stopping flow
	High internal load	Hot air (attic) entering return
		Heat source on; miswired or faulty control
	Restriction in liquid line	Drier plugged.
		Line kinked.
	Low head pressure	Low charge
		Operating in low ambient temperatures
	Suction or liquid line subjected to high heat source	Hot attic
		Hot water line
Low line voltage	Loose wire connections	Check wiring.
	Power company problem, transformer	Report Problem.
	Undersized wire feeding unit	Correct and complete diagnosis.
High line voltage	Power company problem	Report problem.
High head pressure	Overcharge	Check system charge.
	Dirty outdoor coil	Clean coil.
	Faulty or wrong size outdoor fan motor	Replace fan motor.
	Faulty fan blade or wrong rotation	Replace fan blade.
		Replace with correct rotation motor.
	Recirculation of air	Correct installation.
	Additional heat source	Check for dryer vent near unit.
		Check for recirculation from other equipment.
	Noncondensibles	Recover refrigerant. Evacuate and recharge system.
Short cycling of compressor	Equipment not matched	Correct mismatch.
	Cycling or faulty pressure control	Check pressure and address cause of high or low pressure.
		Replace pressure control if faulty.
	Loose wiring	Check unit wiring.
	Thermostat	Located in supply air stream
		Differential setting too close
		Customer misuse
	Indoor coil TXV / Distributor Restriction	Internal foreign matter
		Power element failure
		TXV too small
		Equilizer tube plugged
	Indoor coil distributor tube restricted	Restricted with foreign matter
		Kinked
		Inside diameter reduced from previous compressor failure

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.3 Service Analyzer Charts (cont.)

COMPRESSOR OVERHEATING (cont.)		
SYMPTOM	POSSIBLE CAUSE	CHECK OR REMEDIES
Short cycling of compressor (cont.)	Low charge	Check system charge.
	Low evaporator airflow	Dirty coil
		Dirty filter
		Duct too small or restricted
	Faulty run capacitor	Replace.
	Faulty internal overload	Replace compressor.
Faulty Compressor Valves or scrolls	Fast equalization/Low pressure difference	Replace compressor and examine system to locate reason.
ELECTRICAL		
SYMPTOM	POSSIBLE CAUSE	CHECK OR REMEDIES
Voltage present on load side of compressor contactor and compressor won't run	Internal overload	Allow time to reset.
	Compressor windings	Check for correct ohms.
Voltage present on line side of compressor contactor only	Thermostat	Check for control voltage to contactor coil.
	Compressor control circuit	High-pressure switch
		Low-pressure switch
		Ambient thermostat
		Solid-state protection control or internal thermal sensors
		Compressor timed off/on control or interlock
No voltage on line side of compressor contactor	Blown fuses or tripped circuit breaker	Check for short in wiring or unit.
	Improper wiring	Recheck wiring diagram.
Improper voltage	High voltage	Wrong unit
		Power supply problem
	Low voltage	Wrong unit
		Power supply problem
		Wiring undersized
		Loose connections
	Single Phasing (3 phase)	Check incoming power and fusing.
FLOODED STARTS		
SYMPTOM	POSSIBLE CAUSE	CHECK OR REMEDIES
Liquid in the compressor shell	Faulty or missing crankcase heater	Replace crankcase heater.
Too much liquid in system	Incorrect piping	Check piping guidelines.
	Overcharge	Check and adjust charge.

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.3 Service Analyzer Charts (cont.)

CONTAMINATION		
SYMPTOM	POSSIBLE CAUSE	REMEDY
Moisture	Poor evacuation on installation or during service	In each case, the cure is the same. Recover refrigerant. Add filter drier, evacuate, and recharge.
High head pressure	Noncondensibles air	
Unusual head and suction readings	Wrong refrigerant or mixed refrigerants	
Foreign matter – copper filings	Copper tubing cuttings	
Copper oxide	Dirty copper piping or nitrogen not used when brazing	
Welding scale	Nitrogen not used during brazing	
Soldering flux	Adding flux before seating copper partway	
Excess soft solder	Wrong solder material	
LOSS OF LUBRICATION		
SYMPTOM	POSSIBLE CAUSE	REMEDY
Compressor failures	Vapor line tubing too large	Reduce pipe size to improve oil return.
Low suction pressure	Low charge	Check system charge.
	Refrigerant leaks	Repair and recharge.
Cold, noisy compressor – Slugging	Dilution of oil with refrigerant	Observe piping guidelines.
Noisy compressor	Refrigerant migration in off-cycle	Check or add crankcase heater.
Cold, sweating compressor	Flooding	Check system charge.
Low load	Reduced indoor airflow	Dirty filter
		Dirty indoor coil
		Wrong duct size
		Restricted duct
	Thermostat setting	Advise customer.
Short cycling of compressor	Cycling or faulty high- or low-pressure control	Check pressure and address cause of high or low pressure. Replace pressure control if faulty.
	Loose wiring	Check all control wires.
	Thermostat	In supply air stream, out of calibration
		Customer misuse
SLUGGING		
SYMPTOM	POSSIBLE CAUSE	REMEDY
On start-up	Incorrect piping	Review pipe size guidelines.
TXV hunting when running	Faulty indoor TXV	Replace TXV.

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.3 Service Analyzer Charts (cont.)

FLOODING		
SYMPTOM	POSSIBLE CAUSE	REMEDY
Poor system control using a TXV	Loose sensing bulb	Secure the bulb and insulate.
	Bulb in wrong location	Relocate bulb.
	Wrong size TXV	Use correct replacement.
	Improper superheat setting (less than 5°F [2.8°C])	Replace TXV.
THERMOSTATIC EXPANSION VALVE (TXV)		
SYMPTOM	POSSIBLE CAUSE	REMEDY
High Superheat, Low Suction Pressure (superheat over 15°F [8.3°C])	Moisture freezing and blocking valve	Recover charge, install filter-drier, evacuate system, recharge.
	Dirt or foreign material blocking valve	Recover charge, install filter-drier, evacuate system, recharge.
	Low refrigerant charge	Correct the charge.
	Vapor bubbles in liquid line	Remove restriction in liquid line. Correct the refrigerant charge.
		Remove noncondensable gases.
		Size liquid line correctly.
	Misapplication of internally equalized valve	Use correct TXV.
	Plugged external equalizer line	Remove external equalizer line restriction.
	Undersized TXV	Replace with correct valve.
	Loss of charge from power head sensing bulb	Replace power head or complete TXV.
	Charge migration from sensing bulb to power head (Warm power head with warm, wet cloth. Does valve operate correctly now?)	Ensure TXV is warmer than sensing bulb.
Valve feeds too much refrigerant, with low superheat and higher than normal suction pressure	Moisture causing valve to stick open.	Recover refrigerant, replace filter-drier, evacuate system, and recharge.
	Dirt or foreign material causing valve to stick open	Recover refrigerant, replace filter drier, evacuate system, and recharge.
	TXV seat leak (a gurgling or hissing sound is heard AT THE TXV during the off cycle, if this is the cause). NOT APPLICABLE TO BLEED PORT VALVES.	Replace the TXV.
	Oversized TXV	Install correct TXV.
	Incorrect sensing bulb location	Install bulb with two mounting straps, in 2:00 or 4:00 position on suction line, with insulation.
	Low superheat adjustment	Replace TXV.
	Incorrectly installed, or restricted external equalizer line	Remove restriction, or relocate external equalizer.

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.3 Service Analyzer Charts (cont.)

THERMOSTATIC EXPANSION VALVES (cont.)		
SYMPTOM	POSSIBLE CAUSE	REMEDY
Compressor flood back upon start-up	Refrigerant drainage from flooded evaporator	Install trap riser to the top of the evaporator coil.
	Inoperable crankcase heater or crankcase heater needed	Replace or add crankcase heater.
Superheat is low to normal with low suction pressure	Unequal evaporator circuit loading	Ensure airflow is equally distributed through evaporator.
		Check for blocked distributor tubes.
	Low load or airflow entering evaporator coil	Ensure blower is moving proper air-flow.
		Remove/Correct any airflow restriction.
Superheat and suction pressure fluctuate (valve is hunting)	TXV is oversized	Install correct TXV.
	Sensing bulb is affected by liquid refrigerant or refrigerant oil flowing through suction line	Relocate sensing bulb in another position around the circumference of the suction line.
	Unequal refrigerant flow through evaporator circuits	Ensure sensing bulb is located properly.
		Check for blocked distributor tubes.
	Moisture freezing and partially blocking TXV	Recover refrigerant, change filter-drier, evacuate system, and recharge.
Valve does not regulate at all	External equalizer line not connected or line plugged	Connect equalizer line in proper location, or remove any blockage.
	Sensing bulb lost its operating charge	Replace TXV.
	Valve body damaged during soldering or by improper installation	Replace TXV.

9.0 DIAGNOSTICS & TROUBLESHOOTING

9.4 Troubleshooting Tips

COOLING MODE TROUBLESHOOTING TIPS					
SYSTEM PROBLEM	INDICATORS				
	DISCHARGE PRESSURE	SUCTION PRESSURE	SUPERHEAT Normal: 5°–15°F [2.8° – 8.3°C]	SUBCOOLING Normal: See Charging Chart	COMPRESSOR AMPS
Overcharge	High	High	Low	High	High
Undercharge	Low	Low	High	Low	Low
Liquid Restriction (Filter Drier)	Low	Low	High	High	Low
Low Indoor Airflow	Low	Low	Low	Low	Low
Dirty Outdoor Coil	High	High	Low	Low	High
Low Outdoor Ambient Temperature	Low	Low	High	High	Low
Inefficient Compressor	Low	High	High	High	Low
Indoor TXV Sensing Bulb Charge Lost	Low	Low	High	High	Low
Poorly Insulated Indoor Sensing Bulb	High	High	Low	Low	High

10.0 OUTDOOR UNIT MAINTENANCE



10.1 Outdoor Coil Cleaning

The outdoor fan draws air across the coil during operation which results in contaminants collecting on and between the aluminum fins. These contaminants restrict the air-flow through the coil resulting in reduced capacity and efficiency and increases the temperature of the components that can reduce their life. Therefore, it is recommended that the outdoor coil be cleaned at least annually by a qualified service technician using a non-corrosive coil cleaner and low pressure water hose sprayer. Care must be taken not to damage or flatten out the fins by spraying the fins from

an angle. Washing from the top of the coil down from the inside out is the most effective method of cleaning the coil. The exterior louver panels and unit top are easily removable to facilitate the coil cleaning task.

WARNING: Disconnect electrical power to the unit before removing the top panel or any electrical panel as the fan motor could start at any time and live electrical connections will be exposed.



10.2 Cabinet Cleaning and Care

Annual cleaning of the exterior cabinet is recommended using a mild detergent, water, and cloth/sponge to remove dust, mold, and potentially corrosive contaminants that have collected on the cabinet. It is also recommended to apply a good quality automotive wax to the painted metal cabinet parts annually to protect the finish and to restore the gloss of the paint. Do not apply wax to the plastic parts.



10.3 Motor Lubrication

The bearings in the outdoor motor are pre-lubricated by the motor manufacturer and do not have oiling ports. The motor will run for an indefinite period of time without additional lubrication.



10.4 Replacement Parts

Any replacement part used to replace parts originally supplied on equipment must be the same as or an approved alternate to the original part supplied. The manufacturer will not be responsible for replacement parts not designed to physically fit or operate within the design parameters the original parts were selected for.

11.0 WIRING DIAGRAM

