

BEFORE INSTALLATION

OPTIONAL DEFROST HEATER

The defrost heater prevents freezing of outdoor unit base. The base may freeze when the heating operation is performed for a long time in very low temperature, high humidity condition.

MAC-642BH-U

SG79V248H01

Specifications Rated Voltage 98 / 120 W 208 / 230 V

Electric Power

Do not install the unit by yourself (user). Incomplete installation could cause fire, electric shock, or injury due to the unit falling,

ed inst

Ground the unit correctly. Do not connect the ground to a gas pipe, water pipe, lightning rod, or telephone ground. Defective grounding could cause electric shock.

Depending on the installation area, install a Ground Fault Interrupt (GFI) circuit breaker If the Ground Fault Interrupt (GFI) circuit breaker is not installed, an electric shock could occur

Components

۲

1	Defrost heater	1	4	Cable clamp	1
2	Heater support	1	5	Self drilling screw	2
3	Cable tie	1	6	Wiring diagram	1

1. PREPARING FOR INSTALLATION


Make sure to switch off the power supply or turn off the breaker.
 Remove the top panel, the front panel, the rear guard, the ambient thermistor, and the motor support.


Wear protective equipment such as gloves for your safety.
Be careful not to wet electrical parts with water or snow during installation. Wet electrical parts could cause malfunction.


Do not install the outdoor unit directly on the ground. Install the outdoor unit on a raised platform, such as on racks, to suppress freezing.

2. INSTALLING THE HEATER

- (1) Hold the left lower side of the heat exchanger, and slightly lift up the heat exchanger
- (2) Insert the defrost heater ① under the heat exchanger, and align it with the groove on the base. In order to fix the defrost heater to the base, fix the heater support © to the base with 2 self drilling screws ⑤. (3) Route the lead wires of the defrost heater ①, as shown in the figure below. Secure them with the cable tie ③.
- *If the lead wires slacken, they may touch the propeller fan. Be sure to secure the wires with the cable tie (3) for safety. Cut off the surplus of the cable tie 3.







۲